



Endurocide[®] Antimicro⁺bial **PLUS** Hospital Curtains

Protecting your
staff & patients
all day, everyday

endurocide.com

The facts

Hospital Acquired Infections (HAIs)



In 2016/17 NHS England hospitals had approximately 834,000 HAIs, accounting for an estimated 28,500 deaths⁷



Pathogens such as *C.difficile* spores, MRSA, COVID-19, Measles etc., can survive on surfaces anywhere from a few hours to up to five months^{3,5,6}



Contamination of traditional Curtains can happen rapidly after installation, causing them to become potential sources of pathogenic transmission^{1,4}



Traditional hospital laundering practices are not sufficient to remove all viable bacteria²

93%

of tested laundered fabrics contained bacteria that could result in HAIs², with up to 92% of traditional (fabric) curtains becoming re-contaminated within one week¹

21%

of all bed days across NHS England hospitals in 2016/2017 were due to HAIs, costing some £2.7 billion per year⁷

1. Ohl, Michael; Schweizer, Marin; Graham, Maggie; Heilmann, Kristopher; Boyken, Linda; Diejema, Daniel "Hospital privacy curtains are frequently and rapidly contaminated with potentially pathogenic bacteria" *American Journal of Infection Control* (2012)

2. Karen McIntyre "Hospital Laundering Practices linked to HAIs" www.nonwoven-industry.com (May 2013)

3. Kramer, Axel; Schwekke, Ingeborg and Kampf, Günter "How long do nosocomial pathogens persist on inanimate surfaces? A systematic review" *BMC Infectious Diseases* (2006), 6:130

4. Madeo, Maurice; Green, David; McGregor, Eileen "A study to compare the microbiological contamination of 3 types of hospital privacy curtains with a district general hospital" www.endurocide.com

5. Centers for Disease Control & Prevention "Science Brief: SARS-CoV-2 and Surface (Fomite) Transmission for Indoor Community Environments", April 2021 <https://www.cdc.gov/coronavirus/2019-ncov/more/science-and-research/surface-transmission.html>

6. World Health Organisation "Measles Fact Sheet", December 2019

7. Guest JF, Keating T, Gould D, et al. Modelling the annual NHS costs and outcomes attributable to healthcare-associated infections in England. *BMJ Open* 2020;10:e033367. doi:10.1136/bmjopen-2019-033367

8. Centers for Disease Control & Prevention "HAI and Antibiotic Use Prevalence Survey" <https://www.cdc.gov/hai/eip/antibiotic-use.html>

9. American Hospital Association "Fast Facts on U.S. Hospitals, 2022" <https://www.aha.org/statistics/fast-facts-us-hospitals>

The solution

Endurocide® Antimicrobial **PLUS** Hospital Curtains

Why Antimicrobial Plus?

Unlike other available antimicrobial curtains,
Endurocide® Antimicrobial Plus Curtains are:

- Proven to remain active for up to two years*
- Silver additive free
- Tested and proven to be effective against the top five pathogen groups found in hospitals†


Tested against:†

- ✓ Bacteria
- ✓ Fungi
- ✓ Mycobacteria
- ✓ Spores
- ✓ Viruses

Other important benefits:



PATENTED COATING
for up to two year long life*



REDUCING RISK
& saving valuable time



OVERALL SAVINGS
over two years



PEER REVIEW TESTED
in over eight countries

* **Disclaimer:** Two year long life applies to Endurocide® Antimicrobial Plus Standard Curtains only and whilst Endurocide® Antimicrobial Plus Standard Curtains have been independently tested to remain antimicrobially and sporidically effective for up to two years in-situ, the actual length of curtain use achieved will depend on a variety of factors, including, but not limited to: individual hospital practices; the natural longevity of polypropylene; the risk of the curtain being soiled from items such as blood, urine and general spills; etc. Curtains should always be replaced when visibly soiled. Any timescales provided/referenced are always offered as a guideline only and under no circumstances whatsoever constitute a guarantee. † See individual curtain testing pages for full details on pathogens tested against.

Our technology is different...

Whilst traditional polyester curtains, natural fibre or short-life disposable curtains can easily become **sources of pathogenic transmission within days of installation**, our curtains are different...

At the curtain manufacturing stage, the polypropylene curtain fabric is impregnated with our unique, patented **Endurocide® Curtain Liquid**.


This impregnation coats the curtain fabric creating a polymer layer which has a **dual 'static' and 'cidal' action**.

The 'static' action allows the curtain fabric to **trap pathogens** on the surface of the fabric and prevent them from multiplying, whilst the 'cidal' action then **kills the pathogens** - **helping to break the chain of infection!**

The dual mechanism of trapping and killing the top healthcare pathogen groups on the curtain surface is key - and what makes Endurocide® Antimicrobial Plus Curtains so unique

Breaking the Chain of Infection...

Hand touches contaminated patient, item or surface and **picks up pathogens**




Contaminated hand touches curtain - **pathogens may be transferred to curtain surface**




Our technology in action...

Endurocide® Antimicrobial Plus Curtains
kill the top 5 pathogen groups:*



Endurocide® Antimicrobial Plus Curtains
trap pathogens on the fabric surface,
preventing their escape or multiplication



Once trapped on the curtain surface, the unique impregnation action **kills the pathogens** - and continues to act for up to **two years***

Endurocide® Antimicrobial Plus Curtains
prevent potential retransmission of pathogens to staff, patients, visitors, equipment, surfaces and any other items - **breaking the chain of infection!**

Antimicro⁺bial PLUS

Hospital Curtains – Standard Colours

Laboratory testing

1. Fabric Testing - Trapping pathogens

We use **qualitative** 'Zone of Inhibition' tests to prove that our Endurocide® Curtains both trap pathogens on the surface of our fabric and then prevent the pathogens from growing and reproducing further whilst they are trapped.

These are known as 'static' tests:

- AATCC 147
- CG 147

2. Fabric Testing - Killing pathogens

We use **quantitative** fabric tests to prove that, once pathogens are trapped on the curtain surface, they are then killed – completing our unique dual-action patented protection technology.

These are known as 'cidal' tests:

- AATCC 100
- ISO 20743
- JIS Z 2801

3. One Year & Two Year Testing*

Tests conducted on the Endurocide® Curtain fabric one year and two years after manufacture, to demonstrate that the treated fabric remains active and effective.

- CG 147
- AATCC 100

4. Liquid Testing

Fabric tests against certain viruses, such as Measles and Coronavirus, do not yet exist.

In this situation, to demonstrate our virucidal effectiveness, we instead use quantitative suspension tests against the liquid used to impregnate our Endurocide® Curtains:

- EN 14476

* See website for further details on our one and two year testing



Spores

Clostridium difficile

International Standards

CG 147 AATCC 147
AATCC 100 JIS Z 2801

Mycobacteria

Mycobacterium tuberculosis

International Standards

CG 147

Bacteria

Acinetobacter baumannii

International Standards

CG 147

Acinetobacter baumannii (CRA)

CG 147

Acinetobacter baumannii (MDRA)

CG 147

Enterococcus hirae

CG 147

Escherichia coli

CG 147 AATCC 100

Extended Spectrum Beta-lactamase (ESBL) *Escherichia coli*

CG 147 AATCC 100

Extended Spectrum Beta-lactamase (ESBL) *Klebsiella pneumoniae*

CG 147

Klebsiella pneumoniae

CG 147 ISO 20743

Methicillin-resistant *Staphylococcus aureus* (MRSA)

CG 147 AATCC 100 AATCC 147
AATCC 100 JIS Z 2801

Pseudomonas aeruginosa

CG 147

Salmonella choleraesuis

JIS Z 2801

Salmonella typhimurium

CG 147 AATCC 100

Staphylococcus aureus

ISO 20743 JIS Z 2801

Vancomycin resistant *Enterococcus faecalis* (VRE)

CG 147

Fungi

Aspergillus niger

International Standards

CG 147 AATCC 147

Candida albicans

CG 147 AATCC 147
JIS Z 2801

Candida auris

CG 147 AATCC 147

Liquid treatment testing

Enveloped viruses

Human Coronavirus

International Standards

EN 14476

H1N1 Influenza A virus (Swine Flu)

EN 14476

Measles virus

EN 14476

Fire retardant standards

Our curtains have been tested to the following International fire retardant standards:

Country/Region

International Standards

UK & Europe

BS 5867 Part 2 Types B & C: 2008

USA & Canada

CAN/ULC-S109; NFPA 701: 2010

Australia & New Zealand

AS 2755.2-1985; AS 1530.2-1993 Part 2

Independent Peer Review Trials

Endurocide® Antimicrobial Plus Standard Curtains have been extensively tested in independent international trials and peer reviews:



Scan here to find out more about our international trials:



American Journal of Infection Control 24 month trial¹

In 2016, a report was published in the American Journal of Infection Control testing the antibacterial efficacy of Endurocide® Antimicrobial Plus Standard Curtains 24 months after installation.

Organised by one of Australia's largest public health services, every six months over a period of **24 months** Zone of Inhibition and Contact Inhibition testing was carried out against a range of multi-resistant microorganisms, including:

- Gram positive bacteria (MRSA, VRE *E.faecium*)
- Gram negative bacteria (*Pseudomonas aeruginosa*, ESBL *E.coli*)
- Fungi (*Candida albicans*)
- Spores (*Clostridium difficile*)

* The cost savings were based on comparing the use of Endurocide® Antimicrobial Plus Standard Curtains with traditional cotton cubicle curtains, not only in regards to the initial purchasing costs but to the saving of labour and laundering over two years.



**COST
REDUCTION
50%**

Excellent results were achieved... when tested at baseline, **6, 12, 18 and 24 months**.

There were cost benefits for replacing standard fabric curtains with Endurocide® Curtains... cutting the overall cost by more than 50%.*



1. Kotsanas, Despina; Gillespie, Elizabeth "Disposable antimicrobial and sporicidal privacy curtains: Cost benefit of hanging longer" American Journal of Infection Control, February 25, 2016; DOI:https://doi.org/10.1016/j.ajic.2016.01.009

Hong Kong joint Universities & Government study on bacterial contamination of hospital curtains²

This study, published in the *Journal of Infection Control & Hospital Epidemiology*, evaluated both bioburden and hanging times of three types of curtain – Endurocide® Antimicrobial Plus Standard Curtains, curtains with built-in silver additives and traditional fabric curtains.

Organised jointly between eight hospitals and three government departments in Hong Kong, the study collected culture samples weekly from 12 rooms across 10 hospitals over 12 months to amass significant data before publishing their findings.

The results overwhelmingly supported the continued use of Endurocide® Curtains to improve patient safety by eliminating sources of Multi-drug Resistant Organism (MDRO) transmission.

Standard Curtains

Using Endurocide® Curtains in place of standard curtain:


“ could avert the costs related to curtain changing, laundering, and revenue loss, in addition to improving patient care by removing an environmental source of MDROs.

Results:

Contamination detected on curtains after:*



Percentage of contamination detected in this period:



*Median

2. Shik Luk MBBS, MRCP, FRCPath, FHKCPATH, FHKAM1 et al, "Effectiveness of antimicrobial hospital curtains on reducing bacterial contamination - A multicenter study," *Infection Control & Hospital Epidemiology* (2019), 40, 164–170; DOI:10.1017/ice.2018.315

Antimicro⁺bial PLUS

Hospital Curtains – Printed Colours

Laboratory testing

1. Fabric Testing - Trapping pathogens

We use a **qualitative** 'Zone of Inhibition' test to prove that our Endurocide® Curtains both trap pathogens on the surface of our fabric and then prevent the pathogens from growing and reproducing further whilst they are trapped.

This type of test is known as a 'static' test (see image 1):

■ CG 147

2. Fabric Testing - Killing pathogens

We use a **quantitative** fabric test to prove that, once pathogens are trapped on the curtain surface, they are then killed – completing our unique dual-action patented protection technology.

This type of test is known as a 'cidal' test (see image 2):


■ ISO 20743

3. Liquid Testing

Fabric tests against certain viruses, such as Measles and Coronavirus, do not yet exist.

In this situation, to demonstrate our virucidal effectiveness, we instead use quantitative suspension tests against the liquid used to impregnate our Endurocide® Curtains:

■ EN 14476



Spores

International Standards

Clostridium difficile

CG 147

Bacteria

International Standards

Enterococcus hirae

CG 147

Escherichia coli

CG 147

Klebsiella pneumoniae

CG 147
ISO 20743

Methicillin resistant *Staphylococcus aureus* (MRSA)

CG 147

Salmonella typhimurium

CG 147

Staphylococcus aureus

ISO 20743

Vancomycin resistant *Enterococcus faecalis* (VRE)

CG 147

Fungi

International Standards

Candida albicans

CG 147

Liquid treatment testing

Enveloped viruses

International Standards

Human Coronavirus

EN 14476

H1N1 Influenza A virus (Swine Flu)

EN 14476

Measles virus

EN 14476

Fire retardant standards

Our curtains have been tested to the following International fire retardant standards:

Country/Region

International Standards

UK & Europe

BS 5867 Part 2 Types B & C: 2008

USA & Canada

CAN/ULC-S109; NFPA 701: 2010

Australia & New Zealand

AS 2755.2-1985; AS 1530.2-1993 Part 2





Contents lists available at ScienceDirect

American Journal of Infection Control

journal homepage: www.ajicjournal.org

AJIC
American Journal of
Infection Control

Letters to the editor

Disposable antimicrobial and sporicidal privacy curtains: Cost benefit of hanging longer

To the Editor:

The patient environment may harbor potential pathogens making it a possible source for cross-transmission to the hands of health care workers, patients, and visitors.¹

Privacy curtains surrounding patient beds are constantly touched and may become a reservoir for dissemination.^{2,3} A recent outbreak in an ear, nose, and throat ward revealed 10 fabric curtains were contaminated with the same strain of group A *Streptococcus* as were 3 affected patients in the cancer ward.⁴

Disposable antimicrobial and sporicidal privacy curtains have been marketed over the past few years as a passive infection prevention strategy. New technologies have delivered a variety of treated and embedded substances onto the surfaces of synthetic curtains.⁵ Silver-impregnated curtains were hung in our intensive care unit in 2012 and had excellent antimicrobial and sporicidal activity for 6 months.⁶ Recent formulations have extended protective activity for 2 years, thus providing extra savings related to laundering and labor.

We sought to test antimicrobial activity for 1 antimicrobial and sporicidal product (Endurocide, Aberdeenshire, Scotland), against a range of multiresistant microorganisms to establish activity for the claimed 24-month period.⁷ These curtains are composed of non-woven, extruded polypropylene with 0.5 mm thickness (100 gsm). They are impregnated with a blend of quaternary ammonium chlorides and polyorganosiloxane (a repellent negatively charged silicone) as well as being fire retardant. The biostatic and biocidal properties also prevent bacteria from penetrating or multiplying on the curtain.

Testing followed the same methodology as previously, wherein zone of inhibition and contact inhibition was determined against a range of microorganisms (gram negative: extended-spectrum β -lactamase *Escherichia coli*, *Stenotrophomonas maltophilia*, carbapenemase-producing *Klebsiella pneumoniae*, and *Pseudomonas aeruginosa*; and gram positive: methicillin-resistant *Staphylococcus aureus*, vancomycin-resistant *Enterococcus faecium*, and coagulase-negative staphylococci), *Candida albicans*, and spores of *Clostridium difficile*.⁶

Excellent results were achieved for both zone of inhibition and contact inhibition when tested at baseline, 6, 12, 18, and 24 months with no visible loss of activity (Fig 1).

There were cost benefits for replacing standard fabric curtains with the newer formulation (Endurocide) sporicidal and antimicrobial curtains. The cost of laundering fabric curtains was AUS\$4




Fig 1. Images from 24-month testing for (A) *Clostridium difficile* (zone of inhibition), (B) *Clostridium difficile* (contact inhibition), (C) methicillin-resistant *Staphylococcus aureus* and vancomycin-resistant *Enterococcus faecium* (zone of inhibition), and (D) methicillin-resistant *S aureus* and vancomycin-resistant *E faecium* (contact inhibition).

per screen with a labor cost of AUS\$10 to remove and rehang. Based on a routine schedule of 3 months this would mean 8 changes over 2 years at a total cost of AUS\$112. If ad hoc changes were required due to patients discharged from contact precautions, then an additional cost of AUS\$19 (due to extra setup requirements) would be incurred per episode. The disposable curtains cost AUS\$45 to purchase and AUS\$10 to hang for the 2-year duration, thus cutting the overall cost by more than 50%. In addition, the curtains provide sporicidal and antimicrobial protection to all patients, staff, and visitors accessing the patient area. Another advantage includes a safety advantage for staff members changing the curtains because they are only required to climb ladders once instead of 8 times during a 2-year period.

The final consideration is the environment-related effect of transporting, washing, and reusing fabric curtains compared with the disposable polypropylene curtains that can be recycled via the plastic recycling stream.

Our health service promotes the implementation of the new formulation Endurocide privacy curtains from both a cost-effectiveness and safety perspective.

References

- Cheng VC, Chau PH, Lee WM, Ho SK, Lee DW, So SY, et al. Hand-touch contact assessment of high-touch and mutual-touch surfaces among healthcare workers, patients, and visitors. *J Hosp Infect* 2015;90:220-5.

2. Ohl M, Schweizer M, Graham M, Heilmann K, Boyken L, Diekema D. Hospital privacy curtains are frequently and rapidly contaminated with potentially pathogenic bacteria. *Am J Infect Control* 2012;40:904-6.
3. Das I, Lambert P, Hill D, Noy M, Bion J, Elliott T. Carbapenem-resistant *Acinetobacter* and role of curtains in an outbreak in intensive care units. *J Hosp Infect* 2002;50:110-4.
4. Mahida N, Beal A, Trigg D, Vaughan N, Boswell T. Outbreak of invasive group A *Streptococcus* infection: contaminated patient curtains and cross-infection on an ear, nose and throat ward. *J Hosp Infect* 2014;87:141-4.
5. Schweizer M, Graham M, Ohl M, Heilmann K, Boyken L, Diekema D. Novel hospital curtains with antimicrobial properties: a randomized, controlled trial. *Infect Control Hosp Epidemiol* 2012;33:1081-5.
6. Kotsanas D, Wijesooriya WR, Sloane T, Stuart RL, Gillespie EE. The silver lining of disposable sporicidal privacy curtains in an intensive care unit. *Am J Infect Control* 2014;42:366-70.
7. Endurocide. Antimicrobial and sporicidal curtains. Available from: <http://www.endurocide.com/infection-control/hospital-curains/antimicrobial-and-sporicidal-curains/>. Accessed February 18, 2016.

Despina Kotsanas, MClInEpi, BSc (Hons)*
 Monash Infectious Diseases, Monash Health
 Clayton, Victoria, Australia

Elizabeth Gillespie, MPubHlth(Melb), BN, SIC, RM
 Infection Control and Epidemiology Unit, Monash Health
 Clayton, Victoria, Australia


* Address correspondence to Despina Kotsanas, MClInEpi, BSc (Hons), Monash Infectious Diseases, Monash Health Clayton, Victoria, Australia.
 E-mail address: despina.kotsanas@monashhealth.org (D. Kotsanas).

Conflicts of Interest: None to report.

<http://dx.doi.org/10.1016/j.ajic.2016.01.009>

Our technology in action...

Endurocide® Antimicrobial Plus Curtains kill the top 4 pathogen groups:*



*Disclaimer: Whilst Endurocide® Antimicrobial Plus Curtains - Printed Colours have been independently tested to be antimicrobially and sporicidally effective, the actual length of curtain use achieved will depend on a variety of factors including, but not limited to: individual hospital practices; the natural longevity of polypropylene; the risk of the curtain being soiled from items such as blood, urine and general spills; etc. Curtains should always be replaced when visibly soiled. Any timescales provided/referenced are always offered as a guideline only and under no circumstances whatsoever constitute a guarantee. See individual curtain testing pages for full details on pathogens tested against.



The liquid used to impregnate our Endurocide Antimicrobial Plus Curtains has now been tested to EN 14476 and found to be effective against Vaccinia virus.

What is the Vaccinia virus and why is it important?

Vaccinia virus is a large, complex, enveloped virus belonging to the poxvirus family. Successful testing against Vaccinia virus allows efficacy claims to be made against all enveloped viruses as it is classed as a reference enveloped virus.

This includes claims as to effectiveness against Coronavirus.

Vaccinia is often selected for testing as a substitute for Monkey Pox and other poxviruses, which are difficult to test in laboratories due to their biohazard rating.

Features & benefits

- ✓ Long lasting (up to 24 months)
- ✓ Breaks the chain of infection
- ✓ No laundry costs
- ✓ Fitted with tiebacks
- ✓ Lightweight
- ✓ Self-auditing & privacy labels
- ✓ 100% recyclable
- ✓ No track conversion
- ✓ Fire retardant*

* Meets international standards: NFPA 701, AS 2755.2 - 1985, BS 5867 Part 2 Types B & C 2008, AS 1530.2-1993 Part 2: Test for Flammability of Materials and CAN/ULC-S109

Where to use

Designed for critical hospital and healthcare environments where patient care cannot be compromised.

Suitable for use in hospital departments such as:

- Burns units
- Cardiology wards
- Intensive care units
- Infectious disease units
- Oncology wards
- Renal units
- Maternity & neonatal
- High dependency units
- Operation suites
- Obstetrics
- Rheumatology
- Gynaecology
- General surgery wards
- Isolation wards

Curtain dimensions

| | Standard | Mesh top | Mesh cut | Longdrop |
|--------------|----------|-----------------------------|----------|----------|
| Height | 2.0m | 2.55m (includes 0.55m mesh) | 2.55m | 2.6m |
| Full width | 7.5m | 7.5m | 7.5m | 7.5m |
| Medium width | 5.55m | 5.55m | 5.55m | 5.55m |
| Half width | 3.75m | 3.75m | 3.75m | 3.75m |
| Pleat width | 0.15m | 0.15m | 0.15m | 0.15m |

New Zealand Distributor

Kenco Ltd

Kendyl Carikas

Mobile: 021 029 66718

Email: kendyl.carikas@kenco.nz

Manufactured by



Bio Technics Ltd. Linton Business Park, Gourdon, Aberdeenshire, Scotland, UK DD10 0NH
Tel: +44 (0) 1561 361515 info@endurocide.com endurocide.com

Endurocide® is the healthcare division of Bio Technics Ltd, based in the UK. Endurocide® is a Registered Trademark of Bio Technics Ltd.



Disclaimer: Every effort has been made to ensure that the information presented is correct at the time of publication. However, Bio Technics Ltd does not assume and hereby disclaims any liability to any part for any loss, damage, or disruption caused by errors or omissions resulting from negligence, accident, or any other cause. Bio Technics Ltd makes no reference to any specific brand of competitor products. The data supplied is for guidance purposes only and is therefore without guarantee. Any opinions expressed in this publication are not necessarily those of Bio Technics Ltd and are not for onward publication without consent.